



Masonry



Universita, Aveiro, Portugal





Universita, Budapešť, Maďarsko

Masonry - mostly vertical members

Columns are resistant to vertical actions but sensitive to horizontal actions.

Walls are resistant to vertical and longitudinal actions but sensitive to transverse actions.



Masonry as a structural material


Components

- Masonry units EN 720, strength $f_b = \delta \times f_u$,
 - δ the coefficient of units dimensions,
 - f_u the mean of unit strength,
- Mortar EN 1015-11, e.g. M10, $f_m = 10$ MPa
cement: lime: sand (commonly) 1:1:5

Masonry

- plain masonry
 - normal mortar
 - thin joints
 - light mortar
- reinforced masonry
- prestressed masonry


Compressive zones in plain concrete and masonry





Masonry – historical notes

- Bricks – the oldest artificial construction material – Middle East, Irán – lack of natural stones
- At the beginning shaping (forming) natural materials, later production of bricks from various plastic materials – 9000 years ago


Manufacturing of bicks



Draying technology on a sun




Mesopotamia – Pergamon muzeum



Isájína babylónská brána - Pergamon muzeum Berlin




Samára – 9. století




minaret Abú Dulafovy mešity - Samára 9. století

Samarkand - Registan



Nymburk



Applications

- Widely used material
- economy
- Easy detailing
- Short construction interval
- Reduction of subcontractors
- Human size
- Broad spectrum of units
- Resistance to natural influences
- Minimum maintenance
- Excellent thermal properties
- Small units
- Easy forming
- Great opportunities to architects
- Local raw materials
- Construction periods limited

EN 1996 - Characteristic strength

Masonry strength of plain masonry:

$$f_k = K f_b^{0,65} f_m^{0,25} \quad (\text{newly } f_k = K f_b^{0,7} f_m^{0,3})$$

- K constant dependent on masonry type and units, for masonry without longitudinal joints 0,45 až 0,55
- $f_b = \delta \times f_u$ strength of units < 50 MPa
- δ effect of units dimensions, for CP 290/140/65 $\delta = 0,77$
- f_m strength of mortar < 20 MPa or $< 2 f_b$

An example: $K = 0,5$ (units 2a, without longitudinal joints)

$$f_b = 25 \text{ MPa}, f_m = 15 \text{ MPa}$$

$$f_k = 0,5 \times 25^{0,65} \times 15^{0,25} = 8,0 \text{ MPa}$$

Partial factors γ_M in ENV 1996

| Units class | Production class | | |
|-------------|------------------|-----|-----|
| | A | B | C |
| I | 1,7 | 2,2 | 2,7 |
| II | 2,0 | 2,5 | 3,0 |

Design strength

$$f_d = f_k / \gamma_M$$


Partial factors in EN 1996

| Material | γ_M | | | | |
|---|------------|-----|-----|-----|-----|
| | Class | | | | |
| | 1 | 2 | 3 | 4 | 5 |
| A Masonry made with: | | | | | |
| A Units of Category I, designed mortar ¹ | 1,5 | 1,7 | 2,0 | 2,2 | 2,5 |
| B Units of Category I, prescribed mortar ² | 1,7 | 2,0 | 2,2 | 2,5 | 2,7 |
| C Units of Category II, any mortar ^{1,2,5} | 2,0 | 2,2 | 2,5 | 2,7 | 3,0 |
| D Anchorage of reinforcing steel | 1,7 | 2,0 | 2,2 | 2,5 | 2,7 |
| E Reinforcing steel and prestressing steel | 1,15 | | | | |
| F Ancillary components ^{3,4} | 1,7 | 2,0 | 2,2 | 2,5 | 2,7 |
| G Lintels according to EN 845-2 ³ | 1,5 to 2,5 | | | | |

Notes:


1. Requirements for designed mortars are given in EN 998-2 and EN 1996-2
 2. Requirements for prescribed mortars are given in EN 998-2 and EN 1996-2
 3. Declared values are mean values.
 4. Damp proof courses are assumed to be covered by masonry γ_M .
 5. When the coefficient of variation for Category II units is not greater than 25%.

Simple wall



$h_{\text{ef}} = \rho_n h$
 $\rho_n \leq 1$ reduction coefficient dependent on boundary conditions
 $\rightarrow n = 2, 3, 4.$
 For reinforced concrete slabs $\rho_n = 0,75.$

Rectangular cross section



$$N_{\text{Rd}} = b t f_d \Phi_{i,m}$$

N_{Rd} is design resistance of cross section,

b width of wall,

t thickness of wall (without plaster),

$\Phi_{i,m}$ reduction coefficient.

Reduction coefficient for haed or foot of wall:

$$\Phi_i = (1 - 2 e_i / t)$$

$e_i = e_{fi} + e_a$, is the total eccentricity, $e_i \geq 0,05 t$

$e_{fi} = M_{Edi} / N_{Edi}$ eccentricity due to load

$e_a = h_{\text{ef}} / 450$ random eccentricity/ imperfections.

Middle cross section

Reduction coefficient Φ_m due to eccentricity and slenderness

$$\Phi_m = A_1 \exp(-u^2/2) < 1$$

Coefficient A_1 due to eccentricity dependent on e_{mk} a t :

$$A_1 = 1 - 2 e_{mk}/t,$$

e_{mk} is the total eccentricity $0,33t \geq e_{mk} \geq 0,05 t$

$$e_{mk} = e_{fm} + e_a + e_k, \quad e_m = e_{fm} + e_a$$

load: $e_{fm} = M_{Ed}/N_{Ed}$

imperfections: $e_a = h_{ef}/450,$

creep: $e_k = (0,002 \Phi_\infty h_{ef}/t_{ef}) \sqrt{(t e_m)}$

e_k depends on creep coefficient $\Phi_\infty = \varepsilon_{c,\infty}/\varepsilon_{e1}$, $\varepsilon_{e1} = \sigma/E$: $\Phi_\infty = 0$ to 2 , for stones 0 , fired bricks $0,5$ až $1,5$, concrete units $1,5$ až 2 .

Effect of slenderness


Coefficient $\exp(-u^2/2)$ depends on slenderness λ :

$$u = \frac{\lambda - 0,063}{0,73 - 1,17 \frac{e_{mk}}{t}} \quad \lambda = \frac{h_{ef}}{t_{ef}} \sqrt{\frac{f_k}{E}}$$

Effective thickness t_{ef} equals actual thickness t in case of one layer.

Graphs – tables for $\Phi_m = A_1 \exp(-u^2/2)$ given for the coefficient of masonry defocrmation $\alpha_{sec} = E/f_k (\sim 1000)$, slenderness ratio $h_{ef}/t_{ef} < 27$ (commonly ~ 5 to 10), and eccentricity $e_{mk}/t \geq 0,05$.

Reduction coefficients Φ_m for $\alpha_{sec} = 1000$



An example

Fired bricks $f_u = 25 \text{ MPa}$, units I, production B, $\gamma_M = 2,2$

$K = 0,4$; $f_b = \delta f_u = 0,77 \times 25 = 19,25 \text{ MPa}$; M10: $f_m = 10 \text{ MPa}$

$f_k = 0,4 \times 19,25^{0,65} \times 10^{0,25} = 4,86 \text{ MPa}$, $f_d = f_k / \gamma_M = 4,86 / 2,2 = 2,07 \text{ MPa}$

$M = 0$, $e_{fi} = e_{fm} = 0$; $h_{ef} = 0,75 \times 3,3 = 2,5 \text{ m}$, $b = 1 \text{ m}$, $t = 0,44 \text{ m}$

$$N_{Rd} = \Phi_{i,m} \times b \times t \times f_d = \Phi_{i,m} \times 0,911 \text{ MN}$$

Foot and head of the wall:

$$e_a = h_{ef}/450 = 2,5/450 = 0,0055 \text{ m}$$

$$e_i = e_{fi} + e_a = 0 + 0,0055 (\geq 0,05 t); 0,05 t = 0,05 \times 0,44 = 0,022 \text{ m}$$

$$e_i = 0,022 \text{ m}, \Phi_i = 1 - 2 e_i / t = 1 - 2 \times 0,022 / 0,44 = 0,9$$

$$N_{Rd} = \Phi_i \times b \times t \times f_d = 0,9 \times 1 \times 0,44 \times 2,07 = 0,820 \text{ MN}$$

Middle of the wall:


$e_k = 0$, for $\alpha_{sec} = 1000$, $h_{ef}/t_{ef} = 5,64$ and $e_{mk}/t = 0,05$ graph: $\Phi_m = 0,88$

$$N_{Rd} = \Phi_m \times b \times t \times f_d = 0,88 \times 1 \times 0,44 \times 2,07 = 0,802 \text{ MN}$$

Summary - the most important points

- Masonry components and types of masonry
- Characteristic masonry strength
- Assumed stress distribution of a masonry wall
- Resistance of rectangular head and bottom cross section
- Resistance of rectangular in the middle of the wall
- An example of resistance calculation

Masonry bridge in Switzerland



Alby Sweden



Holýšov in the Czech Republic



Nymburk - renaissance city hall



Nymburk – town walls



Písek – Stone bridge 13 century



Písek - Stone bridge during flooding in
2002



Písek – Stone bridge after flooding in 2002

